

Interchanges, particularly along a given freeway, should be reasonably consistent in their design. A basic principle in the design should be to develop simple open interchanges that are easily traversed and understandable to the driver. Complex interchanges with a profusion of possible travel paths are confusing and hazardous to the motorist and are generally inefficient.

Intersections with minor streets or highways or collector/distributor roads may be accomplished by simple diamond interchanges. The intersection of exit and entrance ramps with the crossroad shall meet all intersection requirements.

The design of freeway exits should conform to the general configurations given in Table 3 – 30 Minimum Deceleration Lengths for Exit Terminals. Exits should be on the right and should be placed on horizontal curves. Where deceleration on an exit loop is required, the deceleration alignment should be designed so the driver receives adequate warning of the approaching increase in curvature. This is best accomplished by gradually increasing the curvature and the resulting centrifugal force. This increasing centrifugal force provides warning to the driver that he must slow down. A clear view of the exit loop should also be provided. The length of deceleration shall be no less than the values shown in Table – 29.

Entrances to freeways should be designed in accordance with the general configurations shown below Table 3 – 29 Minimum Acceleration Lengths for Entrance Terminals. Special care should be taken to ensure vehicles entering from loops are not directed across through travel lanes. The entering roadway should be brought parallel (or nearly so) to the through lanes before entry is permitted. Where acceleration is required, the distances shown in Table 3 – 29 shall, as a minimum, be provided. Exits and entrances to all high-speed facilities (design speed greater than 50 mph), should, where feasible, be designed in accordance with Tables 3 – 30 and 3 – 29. The lengths obtained from Tables 3 – 30 and 3 – 29 should be adjusted for grade by using the ratios in Table 3 – 28.

The selection of the type and exact design details of a particular interchange requires considerable study and thought. The guidelines and design details given in **AASHTO "A Policy on Geometric Design of Highways and Streets" - 2011**, should generally be considered as minimum criteria.

C.9.h Clear Zone

The provisions of ample clear zone or proper redirection of energy absorbing devices is particularly important at intersections. Every effort should be made to open up the area around the intersection to provide adequate clear zone for vehicles that have left the traveled way. Drivers frequently leave the proper travel path due to unsuccessful turning maneuvers or due to the necessity for emergency avoidance maneuvers. Vehicles also leave the roadway after intersection collisions and roadside objects should be removed to reduce the probability of second impacts. The roadside areas at all intersections and interchanges should be contoured to provide shallow slopes and gentle changes in grade.

The roadside clear zone of intersecting roadways should be carried throughout intersections with no discontinuities or interruptions. Poles and support structures for lights, signs, and signals should not be placed in medians or within the roadside clear zone.

The design of guardrails or other barriers should receive particular attention at intersections. Impact attenuators should be used in all gore and other areas where structures cannot be removed.

Particular attention should be given to the protection of pedestrians in intersection areas - **Chapter 8 - Pedestrian Facilities**. Further criteria and requirements for clear zone and protection devices at intersections are given in **Chapter 4 - Roadside Design**.

C.10 Other Design Factors

C.10.a Pedestrian Facilities

The layout and design of the street and highway network should include provisions for pedestrian traffic in urban areas. All pedestrian crossings and pathways within the road right of way should be considered and designed as in integral part of any street or urban highway.

C.10.a.1 Policy and Objectives - New Facilities

The planning and design of new streets and highways shall include provisions for the safe, orderly movement of pedestrian traffic.

The overall objective is to provide a safe, continuous, convenient, and comfortable trip for pedestrian traffic.

C.10.a.2 Accessibility Requirements

Pedestrian facilities, such as sidewalks, shared use paths and transit boarding and alighting areas shall be designed to accommodate people with disabilities. In addition to the design criteria provided in this Manual, the [Department of Transportation ADA Standards for Transportation Facilities \(2006\)](#) and [Department of Justice ADA Standards \(2010\)](#) as required by 49 C.F.R 37.41 or 37.43; and the [2017 Florida Building Code – Accessibility, 6th Edition](#) as required by [Rule Chapter 61G20-4.002, Florida Administrative Code](#) impose additional requirements for the design and construction of pedestrian facilities.

C.10.a.3 Sidewalks

Sidewalks should provide a safe, comfortable space for pedestrians. The width of sidewalks is dependent upon the roadside environment, volume of pedestrians, and the presence of businesses, schools, parks, and other pedestrian attractors. The minimum width for sidewalks is covered in **Chapter 8 – Pedestrian Facilities** and Section C.7.d of this chapter. To ensure compliance with federal and state accessibility requirements:

- Sidewalks less than 60 inches wide must have passing spaces of at least 60 inches by 60 inches, at intervals not to exceed 200 feet.
- The minimum clear width may be reduced to 32 inches for a short distance. This distance must be less than 24 inches long, and separated by 5-foot long sections with 48 inches of clear width.

- Sidewalks not constrained within the roadway right of way with slopes greater than 1:20 are considered ramps and must be designed as such.

Sidewalks 5 feet wide or wider will provide for two adults to walk comfortably side by side.

C.10.a.4 Curb Ramps

In areas with sidewalks, curb ramps must be incorporated at locations where crosswalks adjoin the sidewalks. The basic curb ramp type and design application depends on the geometric characteristics of the intersection or other crossing location.

Typical curb ramp width shall be a minimum of 4 feet with 1:10 curb transitions on each side when pedestrians must walk across the ramp. Ramp slopes shall not exceed 1:12 and shall have a firm, stable, slip resistant surface texture. Ramp widths equal to crosswalk widths are encouraged.

Curb ramps at marked crossings shall be wholly contained within the crosswalk markings excluding any flared sides.

If diagonal ramps must be used, any returned curbs or other well-defined edges shall be parallel to the pedestrian flow. The bottom of diagonal curb ramps shall have 48-inch minimum clear space within the crosswalk. Curb ramps whose sides have returned curbs provide useful directional cues where they are aligned with the pedestrian street crossing and are protected from cross travel by landscaping or street, street furniture, or railings.

It is important for persons using the sidewalk that the location of the ramps be as uniform as possible. Detectable warnings are required at all curb ramps and flush transitions where sidewalks or shared use paths meet a roadway.

The Department's [Standard Plans, Index 522-002](#) provides additional information on the design of accessible sidewalks and shared use paths. Designers should keep in mind there are many

variables involved, possibly requiring each street intersection to have a unique design.

Two ramps per corner are preferred to minimize the problems with entry angle and to decrease the delay to pedestrians entering and exiting the roadway.

C.10.a.5 Additional Considerations

For additional information on pedestrian facilities design, including physical separation from the roadway, over- and underpasses, pedestrian crossings, traffic control, sight distance and lighting, refer to **Chapter 8 – Pedestrian Facilities**.

C.10.b Bicycle Facilities

Provisions for bicycle traffic should be incorporated into the street or highway design. All new roadways and major corridor improvements, except limited access highways, should be designed and constructed under the assumption they will be used by bicyclists. Roadway conditions should be favorable for bicycling. This includes appropriate drainage grates, pavement markings, and railroad crossings, smooth pavements, and signals responsive to bicycles. In addition, facilities such as bicycle lanes, shared use paths, and paved shoulders, should be included to the fullest extent feasible. All flush shoulder arterial and collector roadway sections should be given consideration for the construction of 4-foot or 5-foot paved shoulders. In addition, all curbed arterial and collector sections should be given consideration for bicycle lanes.

For additional information on bicycle facilities design and the design of shared use paths, refer to **Chapter 9 – Bicycle Facilities**.

C.10.c Bridge Design Loadings

The minimum design loading for all new and reconstructed bridges shall be in accordance with **Chapter 17 – Bridges and Other Structures**.

C.10.d Dead End Streets and Cul-de-Sacs

The end of a dead-end street should permit travel return with a turnaround area, considering backing movements, which will accommodate single truck or transit vehicles without encroachment upon private property. Recommended treatment for dead end streets and cul-de-sacs is given in Figure 5-1 Types of Cul-de-Sacs and Dead-End Streets of **AASHTO – "A Policy on Geometric Design of Highways and Streets" - 2011**.

C.10.e Bus Benches and Transit Shelters

Bus benches should be set back at least 10 feet from the travel lane in curbed sections with a design speed of 45 mph or less, and outside the clear zone in flush shoulder sections. See **Chapter 4 – Roadside Design**, Table 4 – 2 Lateral Offset for further information.

Any bus bench or transit shelter adjacent to a sidewalk within the right of way of any street or highway shall be located to leave at least 48 inches of clearance for pedestrians and persons in wheelchairs. An additional one foot of clearance is required when any side of the sidewalk is adjacent to a curb or barrier. Such clearance shall be measured in a direction perpendicular to the centerline of the road. A separate bench pad or sidewalk flare out that provides a 30-inch-wide by 48-inch-deep wheelchair space adjacent to the bench shall be provided. Transit shelters should be set back, rather than eliminated during roadway widening.

Additional information on the design of transit facilities is found in **Chapter 13 – Public Transit** and [Rule Chapter 14-20.003, Florida Administrative Code](#) and [Rule Chapter 14-20.0032, F.A.C.](#)

C.10.f Traffic Calming

Often there are community concerns with controlling travel speeds impacting the safety of a street or highway such as in areas of concentrated pedestrian activities, those with narrow right of way, areas with numerous access points, on street parking, and other similar concerns. Local authorities may elect to use traffic calming design features that could include, but not be limited to, the installation of speed humps, speed tables, chicanes, or other pavement undulations. Roundabouts are also another

method of dealing with this issue at intersections. For additional details and traffic calming treatments, refer to **Chapter 15 – Traffic Calming**.

C.11 Reconstruction

C.11.a Introduction

The reconstruction (improvement or upgrading) of existing facilities may generate equal or greater safety benefits than similar expenditures for the construction of new streets and highways. Modifications to increase capacity should be evaluated for the potential effect on the highway safety characteristics. The long-range objectives should be to bring the existing network into compliance with current standards.

C.11.b Evaluation of Streets and Highways

The evaluation of the safety characteristics of streets and highways should be directed towards the identification of undesirable features on the existing system. Particular effort should be exerted to identify the location and nature of features with a high crash potential. Methods for identifying and evaluating hazards include the following:

- Identification of any geometric design feature not in compliance with minimum or desirable standards. This could be accomplished through a systematic survey and evaluation of existing facilities.
- Review of conflict points along a corridor.
- Information from maintenance or other personnel.
- Review of crash reports and traffic counts to identify locations with a large number of crashes or a high crash rate.
- Review for expected pedestrian and bicycle needs.

C.11.c Priorities

A large percentage of street and highway reconstruction and improvements is directed toward increasing efficiency and capacity. The program of reconstruction should be based, to a large extent, upon priorities for the improvement of safety characteristics.

The priorities for safety improvements should be based on the objective of obtaining the maximum reduction in crash potential for a given expenditure of funds. Elimination of conditions that may result in serious or fatal crashes should receive the highest priority in the schedule for reconstruction.

Specific high priority problem areas that should be corrected by reconstruction include the following:

- Obstructions to sight distance which can be economically corrected. The removal of buildings, parked vehicles, vegetation, large poles or groups of poles that significantly reduce the field of vision, and signs to improve sight distance on curves and particularly at intersections, can be of immense benefit in reducing crashes. The purchase of required line of sight easements is often a wise expenditure of highway funds. The establishment of sight distance setback lines is encouraged.
- Roadside and median hazards which can often be removed or relocated farther from the traveled way. Where removal is not feasible, objects should be shielded by redirection or energy absorbing devices. The reduction of the roadside hazard problem generally provides a good return on the safety dollar. Details and priorities for roadside hazard reduction, which are presented in **Chapter 4 - Roadside Design**, should be incorporated into the overall priorities of the reconstruction program.
- Poor pavement surfaces which have become hazardous should be maintained or reconstructed in accordance with the design criteria set forth in **Chapter 5 - Pavement Design And Construction**, and **Chapter 10 - Maintenance And Resurfacing**.
- Specific design features which could be applied during reconstruction to enhance the operations and safety characteristics of a roadway include the following:
 - Addition of lighting.
 - Frontage roads may be utilized to improve the efficiency and safety of streets and highways with poor control of access.
 - Widening of pavements and shoulders. This is often an economically feasible method of increasing capacity and reducing traffic hazards. Provision of median barriers (**Chapter 4 - Roadside Design**) can also produce significant safety benefits.

- The removal, streamlining, or modification of drainage structures.
- Alignment modifications are usually extensive and require extensive reconstruction of the roadway. Removal of isolated sharp curves is a reasonable and logical step in alignment modification. If major realignment is to be undertaken, every effort should be made to bring the entire facility into compliance with the requirements for new construction.
- The use of traffic control devices. This is generally an inexpensive method of alleviating certain highway defects.
- Median opening modifications.
- Addition of median, channelized islands, and mid-block pedestrian crossings.
- Auxiliary lanes.
- Existing bridges that fail to meet current design standards which are available to bicycle traffic, should be retrofitted on an interim basis as follows: As a general practice, bridges 125 feet in length or longer, bridges with unusual sight problem, steep gradients (which require the cyclist longer time to clear the span) or other unusual conditions should display the standard W11-1 caution sign with an added sign "On Bridge" at either end of the structure. Special care should be given to the right most portion of the roadway, where bicyclists are expected to travel, assuring smoothness, pavement uniformity, and freedom from longitudinal joints, and to ensure cleanliness. Failure to do so forces bicyclists farther into the center portion of the bridge, reducing traffic flow and safety.
- Addition of bicycle facilities.
- Addition of transit facilities, sidewalks, crosswalks, and other pedestrian features.

C.12 Design Exceptions

See **Chapter 14 - Design Exceptions and Variations** for the process to use when the standard criteria found in this Manual cannot be met.

C.13 Very Low-Volume Local Roads (ADT \leq 400)

Where criteria is not specifically provided in this section, the design guidelines presented in Chapter 4 of the [*AASHTO Guidelines for Geometric Design of Very Low-Volume Local Roads \(ADT \$\leq\$ 400\), 1st Edition \(2001\)*](#) may be used in lieu of the policies in Chapter 5 of the AASHTO Policy on Geometric Design of Highways and Streets. See Table 3 – 20 Minimum Lane Widths for lane widths for very low volume roads.

C.13.a Bridge Width

Bridges are considered functionally obsolete when the combination of ADT and bridge width is used in the National Bridge Inventory Item 68 for Deck Geometry to give a rating of 3 or less. To accommodate future traffic and prevent new bridges from being classified as functionally obsolete, the minimum roadway width for new two lane bridges on very low-volume roads with 20 year ADT between 100 and 400 vehicles/day shall be a minimum of 22 feet. If the entire roadway width (traveled way plus shoulders) is paved to a width greater than 22 feet, the bridge width should be equal to the total roadway width. If significant ADT increases are projected beyond twenty years, a bridge width of 28 feet should be considered. One-lane bridges may be provided on single-lane roads and on two-lane roads with ADT less than 100 vehicles/day where a one-lane bridge can operate effectively. The roadway width of a one-lane bridge shall be 15 ft. One-lane bridges should have pull-offs visible from opposite ends of the bridge where drivers can wait for traffic on the bridge to clear.

C.13.b Roadside Design

Bridge traffic barriers on very low-volume roads must have been successfully crash tested to a Test Level 2 (minimum) in accordance with NCHRP Report 350 or Manual for Assessing Safety Hardware (MASH).

THIS PAGE INTENTIONALLY LEFT BLANK

CHAPTER 4

ROADSIDE DESIGN

A	INTRODUCTION.....	4-1
B	ROADSIDE TOPOGRAPHY AND DRAINAGE FEATURES	4-3
B.1	Roadside Slopes, Clear Zone and Lateral Offset	4-3
B.1.a	Roadside Slopes and Clear Zone.....	4-3
B.1.b	Lateral Offset.....	4-11
B.2	Drainage Features.....	4-12
B.2.a	Roadside Ditches.....	4-13
B.2.b	Drainage Structures.....	4-13
B.2.c	Canals and Water Bodies	4-13
B.2.d	Curb.....	4-16
C	ROADSIDE SAFETY FEATURES AND CRASH TEST CRITERIA.....	4-18
C.1	Crash Test Criteria.....	4-18
C.2	Safety Hardware Upgrades.....	4-22
D	SIGNS, SIGNALS, LIGHTING SUPPORTS, UTILITY POLES, TREES AND SIMILAR ROADSIDE FEATURES	4-23
D.1	General	4-23
D.2	Performance Requirements for Breakaway Devices.....	4-23
D.3	Sign Supports	4-23
D.4	Traffic Signal Supports.....	4-24
D.5	Lighting Supports	4-24
D.5.a	Conventional Lighting	4-24
D.5.b	High Mast Lighting	4-25
D.6	Utility Poles	4-25
D.7	Trees.....	4-26
D.8	Miscellaneous	4-26
D.8.a	Fire Hydrants	4-26
D.8.b	Railroad Crossing Warning Devices	4-26
D.8.c	Mailbox Supports	4-26

	D.8.d	Bus Benches and Shelters.....	4-29
E		BARRIERS, END TREATMENTS AND CRASH CUSHIONS.....	4-29
	E.1	Roadside Barriers	4-29
	E.2	End Treatments	4-30
	E.3	Crash Cushions	4-30
	E.4	Performance Requirements	4-30
	E.5	Warrants	4-31
	E.5.a	Above Ground Hazards	4-31
	E.5.b	Drop-Off Hazards.....	4-31
	E.5.c	Canals and Water Bodies	4-32
	E.6	Warrants for Median Barriers	4-32
	E.7	Work Zones and Temporary Barriers.....	4-32
	E.8	Barrier Types	4-34
	E.8.a	Guardrail.....	4-34
	E.8.b	Concrete Barrier.....	4-35
	E.8.c	High Tension Cable Barrier.....	4-36
	E.8.d	Temporary Barrier.....	4-37
	E.8.e	Selection Guidelines	4-38
	E.8.f	Placement.....	4-38
	E.8.f.1	Barrier Offsets	4-38
	E.8.f.2	Deflection Space and Zone of Intrusion	4-40
	E.8.f.3	Grading	4-41
	E.8.f.4	Curbs	4-41
	E.8.f.5	Flare Rate.....	4-41
	E.8.f.6	Length of Need	4-42
	E.8.g	Barrier Transitions.....	4-42
	E.8.h	Attachments to Barriers	4-42
	E.9	End Treatments and Crash Cushions	4-43
	E.9.a	End Treatments for Guardrail	4-43
	E.9.b	End Treatments for Rigid Barrier	4-44
	E.9.c	End Treatments for High Tension Cable Barrier (HTCB) ..	4-44
	E.9.d	End Treatments for Temporary Barrier	4-44
	E.9.e	Crash Cushions	4-44

F	BRIDGE RAILS.....	4-45
G	REFERENCES	4-46

TABLES

Table 4 – 1	Minimum Width of Clear Zone (feet) ¹	4-5
Table 4 – 2	Lateral Offset (feet).....	4-12
Table 4 – 3	Test Levels for Barriers, End Terminals, Crash Cushions	4-20
Table 4 – 4	Test Levels for Breakaway Devices, Work Zone Traffic Control Devices	4-21
Table 4 – 5	Clear Zone Width Requirements for Work Zones	4-33

FIGURES

Figure 4 – 1	Clear Zone Plan View	4-6
Figure 4 – 2	Basic Clear Zone Concept.....	4-7
Figure 4 – 3	Adjusted Clear Zone Concept.....	4-7
Figure 4 – 4	Roadside Ditches – Bottom Width 0 to < 4 Feet	4-9
Figure 4 – 5	Roadside Ditches – Bottom Width ≥ 4 Feet	4-10
Figure 4 – 6	Minimum Offsets for Canal Hazards (Flush Shoulders).....	4-15
Figure 4 – 7	Minimum Offsets for Canal Hazards (Curbed).....	4-16
Figure 4 – 8	Location of Guardrail.....	4-39

CHAPTER 4

ROADSIDE DESIGN

A INTRODUCTION

This chapter presents guidelines and standards for roadside designs intended to reduce the likelihood and/or consequences of roadside crashes. Due to the variety of causative factors, the designer should review crash reports for vehicles leaving the traveled way at any location. On average, lane departure crashes in Florida represent approximately 1/3 of all crashes and almost 50% of all highway fatalities. Construction and maintenance of safe medians and roadsides are of vital importance in the development of safe streets and highways. More information on lane departure crashes in Florida can be found in the Department's [*Florida Strategic Highway Safety Plan*](#).

Many of the standards presented in **Chapter 3 – Geometric Design** are predicated to a large extent upon reducing the probability of vehicles leaving the proper travel path. Other standards in that chapter are directed toward a reduction in the likelihood and/or consequences of crashes by vehicles leaving the roadway, such as shoulders and medians. The design of the roadside beyond the shoulder should also be considered and conducted as an integral part of the total highway design.

The general objective of roadside design is to provide an environment that will reduce the likelihood and/or consequences of crashes by vehicles that have left the traveled way. The achievement of this general objective will be aided by the following:

- Roadside areas adequate to allow reasonable space and time for a driver to regain or retain control of the vehicle and stop or return to the traveled way safely.
- Shoulders, medians, and roadsides that may be traversed safely without vehicle vaulting or overturning.
- Location of roadside fixed objects and hazards as far from the travel lane as is economically feasible.
- Roadsides that accommodate necessary maintenance vehicles, emergency maneuvers and emergency parking.
- Provide adequate shielding of hazards where appropriate and compatible with vehicle speeds and other design variables.

Prior to any other consideration, the designer should, in order of preference, attempt to:

1. Eliminate the hazard
 - a. Remove the hazard
 - b. Redesign the hazard so it can be safely traversed
 - c. Relocate the hazard outside the clear zone
2. Make the hazard crashworthy
3. Shield the hazard with a longitudinal barrier or crash cushion.
4. Delineate the hazard and leave the hazard unshielded. This treatment is taken only when the barrier or crash cushion is more hazardous than the hazard. See Section E.5 for information on making this determination.

This chapter contains standards and general guidelines for situations encountered in roadside design due to the variety and complexity of possible situations encountered. In addressing roadside hazards, the designer should utilize the following as basic guidelines to develop a safe roadside design.

B ROADSIDE TOPOGRAPHY AND DRAINAGE FEATURES

B.1 Roadside Slopes, Clear Zone and Lateral Offset

Providing a sufficient amount of recoverable slope or clear zone adjacent to the roadway, free of obstacles and hazards provides an opportunity for an errant vehicle to safely recover. Minimum standards for roadside slopes, clear zone and lateral offsets to hazards are provided as follows.

B.1.a Roadside Slopes and Clear Zone

The slopes of all roadsides should be as flat as possible to allow for safe traversal by out of control vehicles. A slope of 1:4 or flatter should be used, desirably 1:6 or flatter. The transition between the shoulder and adjacent side slope should be rounded and free from discontinuities. A slope as steep as 1:3 may be used within the clear zone if the clear zone width is adjusted to provide a clear runout area as described below. If sufficient right of way exists, use flatter side slopes on the outside of horizontal curves.

Clear zone is the unobstructed, traversable area beyond the edge of the traveled way for the recovery of errant vehicles. The clear zone includes shoulders and bicycle lanes. The clear zone must be free of aboveground fixed objects, water bodies and non-traversable or critical slopes. Clear zone width requirements are dependent on AADT, design speed, and roadside slope conditions. With regard to the ability of an errant vehicle to traverse a roadside slope, slopes are classified as follows:

1. Recoverable Slope – Traversable Slope 1:4 or flatter. Motorists who encroach on recoverable foreslopes generally can stop their vehicles or slow them enough to return to the roadway safely.
2. Non-Recoverable Slope – Traversable Slope steeper than 1:4 and flatter than 1:3. Non-recoverable foreslopes are traversable but most vehicles will not be able to stop or return to the roadway easily. Vehicles on such slopes typically can be expected to reach the bottom.
3. Critical Slope – Non-Traversable Slope steeper than 1:3. A critical foreslope is one on which an errant vehicle has a higher propensity to overturn.

Clear zone widths for recoverable foreslopes 1V:4H and flatter are provided in Table 4 – 1 Minimum Width of Clear Zone. Clear zone is applied as shown in Figures 4 – 1 Clear Zone Plan View and 4 – 2 Basic Clear Zone Concept. Clear zone is measured from the edge of the traveled way.

On non-recoverable slopes steeper than 1:4 and flatter than 1:3, a high percentage of encroaching vehicles will reach the toe of these slopes. Therefore, the clear zone distance cannot logically end at the toe of a non-recoverable slope. When such non-recoverable slopes are present within the clear zone width provided in Table 4 – 1, additional clear zone width is required. The minimum amount of additional width provided must equal the width of the non-recoverable slope with no less than 10 feet of recoverable slope provided at the toe of the non-recoverable slope. See Figure 4 – 3 Adjusted Clear Zone Concept.

When clear zone requirements cannot be met, see **Sections C, D** and **E** for requirements for roadside barriers and other treatments for safe roadside design. In addition, the **AASHTO Roadside Design Guide (2011)**, and **AASHTO Guidelines for Geometric Design of Very Low Volume Local Roads (ADT ≤ 400) (2001)** may be referenced for a more thorough discussion of roadside design.

Table 4 – 1 Minimum Width of Clear Zone (feet)¹

Design Speed mph	AADT ≥ 1500			AADT < 1500 ^{1, 2}		
	Travel Lanes & Multilane Ramps		Aux Lanes and Single Ramps	Travel Lanes & Multilane Ramp ³ Lane		Aux Lanes and Single Lane Ramps
	1V:6H or flatter	1V:5H to 1V:4H	1V:4H or flatter	1V:6H or flatter	1V:5H to 1V:4H	1V:4H or flatter
≤ 40	14	16	10	10 ²	12 ²	10 ²
45 – 50	20	24	14	14	16	14
55	22	26	18	16	20	14
60	30	30 ³	24	20	26	18
65 – 70	30	30 ³	24	24	28	18

1. Clear Zone for roads functionally classified as Local Roads with a design AADT ≤ 400 vehicles per day:


- A clear zone of 6 feet or more in width must be provided if it can be done so with minimum social/environmental impacts.
- Where constraints of cost, terrain, right of way, or potential social/environmental impacts make the provision of a 6 feet clear zone impractical, clear zones less than 6 feet in width may be used, including designs with 0 feet clear zone.
- In all cases, clear zone must be tailored to site-specific conditions, considering cost-effectiveness and safety tradeoffs. The use of adjustable clear zone widths, such as wider clear zone dimensions at sharp horizontal curves where there is a history of run-off-road crashes, or where there is evidence of vehicle encroachments such as scarring of trees or utility poles, may be appropriate. Lesser values of clear zone width may be appropriate on tangent sections of the same roadway.
- Other factors for consideration in analyzing the need for providing clear zones include the crash history, the expectation for future traffic volume growth on the facility, and the presence of vehicles wider than 8.5 feet and vehicles with wide loads, such as farm equipment.

2. May be reduced to 7 feet for a design AADT < 750 vehicles per day.


3. Greater clear zone widths provide additional safety for higher speed and volume roads. See Section 3.1 of the [AASHTO Roadside Design Guide \(2011\)](#) for further information.

Source: Table 3 – 1, Suggested Clear Zone Distances in Feet from the Edge of the Travel Lane, 2011 AASHTO Roadside Design Guide.

Figure 4 – 1 Clear Zone Plan View



Two Lane, Two -Way Roadway



Multi-Lane Two-Way Roadway

Note: 1. Lateral offset is measured out from the centerline of roadway and edge of traveled way or face of curb to a roadside object or feature.

Figure 4 – 2 Basic Clear Zone Concept






Figure 4 – 3 Adjusted Clear Zone Concept




Roadside ditches may be included within the clear zone if properly designed to be traversable. Acceptable cross section slope criteria for roadside ditches within the clear zone is provided in Figure 4 – 4 Roadside Ditches – Bottom Width 0 to < 4 Feet and Figure 4 – 5 Roadside Ditches – Bottom Width \geq 4 Feet. These roadside ditch configurations are considered traversable.

Figure 4 – 4 Roadside Ditches – Bottom Width 0 to < 4 Feet



Source: Figure 3 – 6, 2011 AASHTO Roadside Design Guide.

Figure 4 – 5 Roadside Ditches – Bottom Width \geq 4 Feet



Source: Figure 3 – 6, 2011 AASHTO Roadside Design Guide.

B.1.b Lateral Offset

Lateral offset is the lateral distance from a specified point on the roadway such as the edge of traveled way or face of curb, to a roadside feature or above ground object that is more than 4 inches above grade. Lateral offset requirements apply to all roadways. The requirements for various objects or features are based on:

- Design speed,
- Location; i.e. rural areas or within urban boundary,
- Flush shoulder or with curb,
- Traffic volumes, and
- Lane type; e.g. travel lanes, auxiliary lanes, and ramps.

Lateral Offset requirements are provided in Table 4 – 2 Lateral Offset.

Flush shoulder roadways typically have sufficient right of way to provide the required clear zone widths. Therefore, lateral offset requirements for these type roadways are based on providing the clear zone widths provided in Table 4 – 1. Minimum Width of Clear Zone.

On urban curbed roadways with design speeds ≤ 45 mph, lateral offsets based on Table 4 – 1 clear zone requirements should be provided where practical. However, these urban low speed roads are typically located in areas where right of way is restricted (characterized by more dense abutting development, presence of parking, closer spaced intersections and accesses to property, and more bicyclists and pedestrians). The available right of way is typically insufficient to provide the required clear zone widths. Therefore, lateral offset requirements for above ground objects on these roadways are based on offsets needed for normal operation and not on maintaining a clear roadside for errant vehicles.

Table 4 – 2 Lateral Offset (feet)

Roadside Feature	Urban Curbed Roadways Design Speed ≤ 45 (mph)	All Other
Above Ground Objects ¹	4 ft. from Face of Curb ²	Clear Zone Width
Drop Off Hazards ³	Clear Zone Width	Clear Zone Width
Water Bodies	Clear Zone Width	Clear Zone Width
Canal Hazards	See Section B.2.c	See Section B.2.c

1. Above ground objects are anything greater than 4 inches in height and are firm and unyielding or do not meet crashworthy or breakaway criteria. For urban curbed areas ≤ 45 mph this also includes crashworthy or breakaway objects except those necessary for the safe operation of the roadway.

2. May be reduced to 1.5 ft. from Face of Curb on roads functionally classified as Local Streets and on all roads where the 4 ft. minimum offset cannot be reasonably obtained and other alternatives are deemed impractical.

3. Drop off hazards are:

- Any vertical faced structure with a drop off (e.g. retaining wall, wing-wall, etc.) located within the Clear Zone.
- Slopes steeper than 1:3 located within the Clear Zone.
- Drop-offs with significant crash history.

B.2 Drainage Features

Drainage design is an important aspect of the long-term performance of a roadway, and to achieve an effective design, drainage features are necessary in close proximity to travel lanes. These features include ditches, curbs, and drainage structures (e.g. transverse/parallel pipes, culverts, endwalls, wingwalls, and inlets). The placement of these features is to be evaluated as part of roadside safety design. Refer to **Chapter 20 – Drainage** for information regarding proper hydraulic design.

When evaluating the design of roadside topography and drainage features, consider the future maintenance implications of the facility. Routine maintenance or repairs needed to ensure the continued function of the roadway slopes or

drainage may lead to long-term expenses and activities, which disrupts traffic flow and exposes maintenance personnel to traffic conditions.

B.2.a Roadside Ditches

Minimum standards for side slopes and bottom widths of roadside ditches and channels within the clear zone are provided in Section B.1.a.

B.2.b Drainage Structures

Drainage structures and their associated end treatments located along the roadside should be implemented using either a traversable design or located outside the required clear zone. The various drainage inlets and pipe end treatments needed for an efficient drainage design typically contain curb inlets, ditch bottom inlets, endwalls, wingwalls, headwalls, flared end sections and/or mitered end sections. If not adequately designed or properly located, these features can create hazardous conditions (e.g. abrupt deceleration or rollovers) for vehicles. For detailed background information concerning traversable designs, refer to the ***AASHTO Roadside Design Guide***.

Standard details for drainage structures and end treatments commonly used in Florida are provided in the Department's [***Standards Plans Index 425, 430, and 436 Series***](#). Drainage features shown in the Department's ***Standard Plans*** have the potential for conflict with a vehicle either departing the roadway or within a commonly traversed section of a roadway. The Department's ***Drainage Manual*** identifies those standard drainage structures which are acceptable for use within the clear zone.

B.2.c Canals and Water Bodies

Roadside canals and other bodies of water close to the roadway should be eliminated wherever feasible. When not feasible, they should be located outside of the clear zone as shown in Table 4 – 1 Minimum Width of Clear Zone. If the body of water meets the definition of a canal hazard, additional lateral offset is required for arterial and collector roadways.

A canal hazard is defined as an open ditch parallel to the roadway for a minimum distance of 1,000 feet and with seasonal water depth more than 3 feet for extended periods of time (24 hours or more).

Canal hazard lateral offset is the distance from the edge of travel lane, auxiliary lane or ramp to the top of the canal side slope nearest the road. Minimum required lateral offset distances are as follows:

- Not less than 60 feet for flush shoulder and curbed roadways with design speeds of 50 mph or greater.
- Not less than 50 feet for flush shoulder roadways with design speeds of 45 mph or less.
- Not less than 40 feet for curbed roadways with design speeds of 45 mph or less.

See also Figure 4 – 6 Minimum Offsets for Canal Hazards (Flush Shoulders) and Figure 4 – 7 Minimum Offsets for Canal Hazards (Curb and Curb and Gutter). On new alignments and/or for new canals, greater distances should be provided to accommodate future widening of the roadway.


On fill sections, a flat berm (maximum 1:10 slope) no less than 20 feet in width between the toe of the roadway front slope and the top of the canal side slope nearest the roadway should be provided.

When the slope between the roadway and the "extended period of time" water surface is 1:6 or flatter, the minimum distance can be measured from the edge of the travel lane, auxiliary lane, or ramp to the "extended period of time" water surface. A berm is not required.


On sections with ditch cuts, a minimum of 20 feet between the toe of the front slope and the top of the canal side slope nearest the roadway should be provided.

When the required minimum lateral offset cannot be met, the canal hazard shall be shielded with a crashworthy roadside barrier. Barriers shall be located as far from the traveled way as practical. When shielding canal hazards the barrier shall be located outside the clear zone where possible. Guardrail shall be located no closer than 6 feet from the canal front slope and high tension cable barrier shall be no closer than 15 feet from the canal front slope.

Figure 4 – 6 Minimum Offsets for Canal Hazards
(Flush Shoulders)



**Figure 4 – 7 Minimum Offsets for Canal Hazards
(Curbed)**



B.2.d Curb

Curbs with closed drainage systems are typically used in urban areas to minimize the amount of right of way needed. Curbs also provide a tangible definition of the roadway limits and delineation of access points. These functions are important in urban areas because of the following typical characteristics:

- Low design speed (Design Speed \leq 45 mph);
- Dense abutting development;
- Closely spaced intersections and accesses to property;
- Higher number of motorized vehicles, bicyclists and pedestrian volumes, and;
- Restricted right of way.

Chapter 3 – Geometric Design provides criteria on the use of curbs. It should be noted that curbs have no redirection capabilities except at very low speeds; less than the lowest design speeds typically used for urban streets. Therefore, curbs are not considered to be effective in shielding a hazard and are not to be used to reduce lateral offset requirements.

The Department's [Standard Plans, Index 520-001](#) provides standard details for curb shapes commonly used in Florida. Typical applications for urban roadways include Type E and Type F curbs. Both curb types have a sloped face; however, the Type E has a flatter face to allow vehicles to traverse it more easily. Shoulder gutter is also frequently used along roadway fill sections and bridge approaches to prevent excessive runoff down embankment slopes. The Department's ***Drainage Manual*** may be referenced for direction on the use of shoulder gutter.

Curbs types such as Type E (height 5" or less with a sloping face equal to or flatter than the Type E) may be used in the following cases on high speed roadways. The face of the curb shall be placed no closer to the edge of the traveled way than the required shoulder width.

- High speed multilane divided highways with design speeds of 55 mph and less. For examples see the Department's [Design Manual, Chapter 210 Arterials and Collectors](#).
- Directional Median Openings. For examples see the Department's [Design Manual, Chapter 212 Intersections](#).
- Transit Stops (harmonize with flush shoulder accessible transit stops).

C ROADSIDE SAFETY FEATURES AND CRASH TEST CRITERIA

While a traversable and unobstructed roadside is highly desirable from a safety standpoint, some appurtenances near the traveled way are necessary. Man-made fixed objects that frequently occupy road rights-of-way include traffic signs, traffic signals, roadway lighting, railroad warning devices, intelligent transportation systems (ITS), utility poles, mailboxes. Other features include safety hardware such as barriers, end treatments and crash cushions which are often necessary to shield errant motorists from a variety of roadside hazards.

These features are in addition to trees and other vegetation often present, either naturally occurring or as part of landscaping. Applicable criteria for each of these features is presented in the following sections. Certain features are required to meet specific crash test criteria involving full scale crash testing.

C.1 Crash Test Criteria

Crash test criteria for roadside safety features has been in existence since 1962, but has changed over time as the vehicle fleet changes, and crash characteristics and hardware performance becomes better understood. [NCHRP Report 350, Recommended Procedures for the Safety Performance Evaluation of Highway Features](#), published in 1993, has been the accepted criteria for safety hardware device testing for many years.

More recently, the [AASHTO Manual for Assessing Safety Hardware \(MASH\)](#) was published and has superseded **NCHRP Report 350** as the most current criteria. To allow adequate time for the testing and development of features under MASH criteria, safety hardware installed on new and reconstruction projects shall meet **NCHRP Report 350** crash test criteria as a minimum. For projects on the National Highway System, a schedule has been established for implementing requirements for devices meeting MASH criteria. For more information see FHWA's web site for [Roadway Departure Safety](#). New and reconstruction projects not on the National Highway System are not required to conform to this implementation schedule, but should comply to the extent practical.

The Department maintains standard details, specifications and approved products for all types of roadside devices commonly used in Florida that meet the required crash test criteria, and are acceptable for use on all public roadways. Non-proprietary, standardized devices are detailed in the Departments [Standard](#)

[Plans, Indexes 521, 536, and 544 Series](#). Proprietary products are included on the Department's [Approved Product List \(APL\)](#). These devices address the majority of roadside needs for all roads in Florida. The most current version of the **Standard Plans** and **APL** should be used as the Department maintains and updates these publications as necessary to comply with required implementation dates for changes in crash test criteria.

For cases where a device may be needed that is not covered by the Department's standards and approved products, the Federal Highway Administration (FHWA) maintains lists of eligible crashworthy devices, which can be found on their website for [Roadway Departure Safety](#). In addition, the AASHTO-Associated General Contractors of America (AGC)-American Road and Transportation Builders Association (ARTBA) Joint Committee Task Force 13 report, [A Guide to Standardized Highway Barrier Hardware](#), provides engineering drawings for a multitude of barrier components and systems.

The criteria for crash testing specified in **NCHRP Report 350** and **AASHTO MASH** provides six Test Levels (TL-1 thru TL-6) for the evaluation of roadside hardware suitability. A test level is defined by impact speed and angle of approach, and the type of test vehicle. Test vehicles range in size from a small car to a loaded tractor trailer truck. Each Test Level provides an increasing level of service in ascending numerical order.

Tables 4 – 3 Test Levels for Barriers, End Terminals, Crash Cushions and 4 – 4 Test Levels for Breakaway Devices, Work Zone Traffic Control Devices summarize the vehicle types, vehicle mass, test speeds and impact angles used in testing for each test level. Tables 4 – 3 and 4 – 4 also show the differences in vehicle mass between MASH and **NCHRP Report 350** criteria for the small car, pickup and single unit truck test vehicles.

In addition to differences in vehicle mass, MASH test criteria incorporated several other changes that differ from **NCHRP Report 350**. For additional information on crash test criteria, refer to the **AASHTO MASH**, **NCHRP Report 350**, the **AASHTO Roadside Design Guide**, and the FHWA web site for **Roadway Departure Safety**.

Table 4 – 3 Test Levels for Barriers, End Terminals, Crash Cushions

Test Level	Test Vehicle Type	Vehicle Designation and Mass		Test Conditions MASH	
		NCHRP 350 (lbs.)	MASH (lbs.)	Impact Speed (mph)	Impact Angle (for Barriers) (degrees)
1	Passenger Car	820C 1800	1100C 2420	31	25
	Pickup Truck	2000P 4400	2270P 5000	31	25
2	Passenger Car	820C 1800	1100C 2420	44	25
	Pickup Truck	2000P 4400	2270P 5000	44	25
3	Passenger Car	820C 1800	1100C 2420	62	25
	Pickup Truck	2000P 4400	2270P 5000	62	25
4	Passenger Car	820C 1800	1100C 2420	62	25
	Pickup Truck	2000P 4400	2270P 5000	62	25
	Single-Unit Truck	8000S 17640	10000S 22000	56	15
5	Passenger Car	820C 1800	1100C 2420	62	25
	Pickup Truck	2000P 4400	2270P 5000	62	25
	Tractor-Van Trailer	36000V 79300	36000V 79300	50	15
6	Passenger Car	820C 1800	1100C 2420	62	25
	Pickup Truck	2000 4400	2270P 5000	62	25
	Tractor-Tank Trailer	36000V 79300	36000V 79300	50	15

Note: Test Levels 1, 2 and 3 apply to end terminals and crash cushions, while all 6 Test Levels apply to barriers.

Table 4 – 4 Test Levels for Breakaway Devices, Work Zone Traffic Control Devices

Test Level	Feature	Test Vehicle Type	Vehicle Designation and Mass		Impact Speeds		Impact Angle (degrees)
			NCHRP 350 (lbs.)	MASH (lbs.)	Low Speed (mph)	High Speed (mph)	
2	Support Structures and Work Zone Traffic Control Devices	Passenger Car Pickup Truck	820C 1800 Not Required	1100 2420 C 5000 2270P	19 19	44 44	0 – 20 0 – 20
	Breakaway Utility Poles	Passenger Car Pickup Truck	820C 1800 Not Required	1100 2420 C 5000 2270P	31 31	44 44	0 – 20 0 – 20
3	Support Structures and Work Zone Traffic Control Devices	Passenger Car Pickup Truck	820C 1800 Not Required	1100 2420 C 5000 2270P	19 19	62 62	0 – 20 0 – 20
	Breakaway Utility Poles	Passenger Car Pickup Truck	820C 1800 Not Required	1100 2420 C 5000 2270P	31 31	62 62	0 – 20 0 – 20

Note: Criteria for Test Levels 2 and 3 are provided for support structures, work zone traffic control devices and breakaway utility poles. Test Level 3 is the basic test level used for most devices.

As noted in Tables 4 – 3 and 4 – 4, Test Levels 1 through 3 are limited to passenger vehicles while Test Levels 4 through 6 incorporate heavy trucks. The test speeds and impact angles used for testing represent approximately 92.5% of real world crashes. As implied by the information in Tables 4 – 3 and 4 – 4:

1. Test Level 1 devices should be used only on facilities with design speeds 30 mph and less.

2. Test Level 2 devices should be used only on facilities with design speeds 45 mph and less.
3. Test Level 3 through Test Level 6 devices are considered acceptable for all design speeds.
4. Test Level 3 devices are generally considered acceptable for facilities of all types and most roadside conditions.
5. Test Levels 4 through 6 should be considered on facilities with high volumes of heavy trucks and/or where penetration beyond the barrier would result in high risk to the public or surrounding facilities.

For additional information regarding appropriate application of Test Levels refer to the [***AASHTO Roadside Design Guide***](#).

C.2 Safety Hardware Upgrades

On new construction and reconstruction projects existing obsolete safety hardware shall be upgraded or replaced with hardware meeting crash test criteria as described above.

For existing roadways, highway agencies should upgrade existing highway safety hardware to comply with current crash test criteria either when it becomes damaged beyond repair, or when an individual agency's maintenance policies require an upgrade to the safety hardware.

The Department's [***Design Manual, Chapter 215 Roadside Safety***](#) provides a list of considerations when investigating the need for upgrading barriers and other hardware. The Department's [***Design Standards***](#) provide standard details for transitioning new barriers to existing barriers. The [***AASHTO Roadside Design Guide***](#) also provides guidelines for upgrading hardware.

D SIGNS, SIGNALS, LIGHTING SUPPORTS, UTILITY POLES, TREES AND SIMILAR ROADSIDE FEATURES

D.1 General

This section provides criteria for traffic sign supports, signal supports, lighting supports, utility poles, trees and similar roadside features.

Generally, those roadside appurtenances and features that cannot be removed or located outside the clear zone must meet breakaway criteria to reduce impact severity. For those features located within the clear zone where it is not practical to meet breakaway criteria, shielding may be warranted and shall be considered.

D.2 Performance Requirements for Breakaway Devices

The term breakaway support refers to traffic sign, highway lighting, and other supports that are designed to yield, fracture, or separate when impacted by a vehicle. The release mechanism may be a slip plane, plastic hinge, fracture element, or combination thereof. Crash test criteria applicable to breakaway devices are presented in Section C. Additional requirements for breakaway supports are provided in the [*AASHTO Standard Specifications for Structural Supports for Highway Signs, Luminaries, and Traffic Signals*](#). For a more detailed discussion on breakaway supports, refer to the [*AASHTO Roadside Design Guide*](#).

See Section C for references that provide additional information and details on crash tested breakaway supports.

D.3 Sign Supports

Traffic signs and sign supports shall meet the requirements provided in the [*Manual on Uniform Traffic Control Devices \(MUTCD\)*](#) as stated in **Chapter 18 – Signing and Marking**. The **MUTCD** requires all sign supports within the clear zone to be shielded or breakaway. See Section B for clear zone requirements. Only when the use of breakaway supports is not practicable should a traffic barrier or crash cushion be used exclusively to shield sign supports. In addition, sign supports should be located where they are least likely to be hit. Where possible, signs should be placed behind existing roadside barriers beyond the design deflection distance or on existing structures.

The [Department's Standard Plans, Index 700 Series](#) provides details for breakaway supports for single and multi-post ground mounted signs that are acceptable for use within the clear zone. The most current version of these [Standard Plans](#) details should be used as the Department maintains and updates these details as necessary to comply with required implementation dates for changes in crash test criteria.

Overhead signs and cantilever signs require relatively large size support systems. The potential safety consequences of these systems falling necessitate a fixed-base design that cannot be made breakaway. Overhead sign and cantilever sign supports therefore are required to be located outside the clear zone (Section B) or be shielded with a crashworthy barrier (Section E). Where possible, these supports should be located behind traffic barriers shielding nearby overpasses or other existing structures, or the signs should be mounted on the nearby structure. The Department's [Standard Plans, Indexes 700-012 and 700-013](#) provide details and instructions for the design of these systems.

D.4 Traffic Signal Supports

Traffic signal supports commonly used in Florida are fixed base and shall meet the required lateral offset and clear zone criteria provided in Section B. Traffic signal supports should not be located within medians. The Department's [Standard Plans, Indexes 641-010, 649-010, and 649-030](#) provide details and instructions for the design of traffic signal supports.

D.5 Lighting Supports

Lateral offset criteria for lighting supports depend on whether the support is breakaway or fixed base as discussed below. See **Chapter 6 - Lighting** for additional design criteria for lighting.

D.5.a Conventional Lighting

Supports for conventional lighting (heights up to 60 feet) shall be breakaway which are typically frangible bases (cast aluminum transformer bases), slip bases, or frangible couplings (couplers). The Department's [Standard Plans, Indexes 715-001 and 715-002](#) provide further information for breakaway lighting supports which are acceptable for use. As a general rule, a breakaway lighting support will fall near the line of the path of an

impacting vehicle. The mast arm usually rotates and points away from the roadway when resting on the ground. For poles located on the outside of the roadway (not in medians), this action generally results in the pole not falling into other traffic lanes. However, the designer should remain aware that these falling poles may endanger other motorists or bystanders such as pedestrians and bicyclists. The [AASHTO Roadside Design Guide](#) may be referenced for additional discussion on breakaway lighting supports.

On curbed roadways with design speeds 45 mph or less, breakaway lighting supports shall be located to meet lateral offset requirements provided in Section B, Table 4 – 2.

On flush shoulder roadways, breakaway lighting supports shall be located a minimum of 20 feet from the nearest travel lane, 14 feet from the nearest auxiliary lane or outside the clear zone provided in Section B, Table 4 – 1, whichever is less. The foreslope shall be 1:6 or flatter in cases where supports are located within the clear zone.

Lighting should not be located in medians, except in conjunction with barriers that are justified for other reasons.

D.5.b High Mast Lighting

High mast or high-level lighting supports are fixed-base support systems that do not yield or break away on impact. High mast lighting supports shall be located outside the clear zone provided in Section B, Table 4 – 1. High mast lighting shall not be located in medians except in conjunction with barriers that are justified for other reasons. The Department's [Standard Plans, Index 715-010](#) provides additional information.

D.6 Utility Poles

Utility poles shall be located to meet lateral offset and clear zone requirements provided in Section B and be located as close as practical to the right of way line. They should be installed per the permitting agency's requirements. The [AASHTO Roadside Design Guide](#) provides additional discussion and guidance on utility poles.

In accordance with **Section 337.403, Florida Statutes**, existing utility poles must be relocated when *unreasonably* interfering with the "convenient, safe, or continuous use, or the maintenance, improvement, extension, or expansion" of public roads. Utility poles adjacent to road improvement projects, but not directly interfering with construction, should be considered for relocation, to the extent they can be relocated, to achieve the clear zone requirements of Table 3-12. Utility poles that cannot be relocated and will remain within the clear zone, should be approved through the exception process prescribed in **Chapter 14 - Design Exceptions**.

D.7 Trees

Trees with a diameter greater than 4 inches measured 6 inches above grade shall be located to meet lateral offset and clear zone requirements in Section B, Tables 4 – 1 and 4 – 2. The [AASHTO Roadside Design Guide](#) provides additional discussion and guidance on trees.

D.8 Miscellaneous

D.8.a Fire Hydrants

Most fire hydrants are made of cast iron and are expected to fracture upon impact, however, crash testing meeting current criteria has not been done to verify that designs meet breakaway criteria. For this reason, fire hydrants should be located as far from the traveled way as practical and preferably outside lateral offset/clear zone requirements in Section B, yet where they are still readily accessible to and usable by emergency personnel. Any portion of the hydrant not designed to break away should be within 4 inches of the ground.

D.8.b Railroad Crossing Warning Devices

See **Chapter 7 – Rail-Highway Crossings** for location requirements for railroad crossing warning devices.

D.8.c Mailbox Supports

Mailboxes and their location are subject to US Postal Service requirements. They are often located within the clear zone and pose a potential hazard.

However, with proper design and placement, the severity of impacts with mailboxes can be reduced. To achieve consistency, it is recommended each highway agency adopt regulations for the design and placement of mail boxes within the right of way of public highways. The [AASHTO Roadside Design Guide](#) provides a model regulation that is compatible with US Postal Service requirements.

The following requirements apply to mailbox installations on public roadways:

No mailbox will be permitted where access is obtained from a freeway or where access is otherwise prohibited by law or regulation. Mailboxes shall be located as follows:

- On the right-hand side of the roadway in the carrier's direction of travel except on one-way streets, where they may be placed on the left-hand side.
- Where a mailbox is located at a driveway entrance, it shall be placed on the far side of the driveway in the carrier's direction of travel.
- Where a mailbox is located at an intersecting road, it shall be located a minimum of 200 feet beyond the center of the intersecting road in the carrier's direction of travel. This distance may be decreased to 100 feet on very low volume roads.
- When a mailbox is installed in the vicinity of an existing guardrail, it should, when practical, be placed behind the guardrail.

The bottom of the box shall be set at a height established by the U. S. Postal Service, usually from 41 to 45 inches above the roadway surface.

On flush shoulder roadways, the roadside face of the box should be offset from the edge of the traveled way a distance no less than the greater of the following:

- 8 feet (where no paved shoulder exists and shoulder cross slope is 10 percent or flatter), or
- width of the shoulder present plus 6 to 8 inches, or
- width of a turnout specified by the jurisdiction plus 6 to 8 inches.

On very low volume flush shoulder roads with low operating speeds the offset may be reduced to 6 feet from the traveled way.

On curbed streets, the roadside face of the mailbox should be set back from the face of the curb at a distance of 6 to 8 inches. On residential streets without curbs or all-weather shoulders that carry low traffic volumes operating at low speeds, the roadside face of the mailbox should be offset between 8 inches and 12 inches behind the edge of the pavement.

Design criteria for the mailbox support structure when located within the clear zone should consist of the following:

- Mailboxes shall be of light sheet metal or plastic construction conforming to the requirements of the U. S. Postal Service. Newspaper delivery boxes shall be of light metal or plastic construction of minimum dimensions suitable for holding a newspaper.
- No more than two mailboxes may be mounted on a support structure unless crash tests have shown the support structure and mailbox arrangement to be safe. However, light-weight newspaper boxes may be mounted below the mailbox on the side of the mailbox support.
- A single 4 inch by 4 inch square or 4 inch diameter wooden post; or metal post, Schedule 40, 2 inch (normal size IPS (external diameter 23/8 inch) (wall thickness 0.154 inches) or smaller), embedded no more than 24 inches into the ground, shall be acceptable as a mailbox support. A metal post shall not be fitted with an anchor plate, but it may have an anti-twist device that extends no more than 10 inches below the ground surface.
- Unyielding supports such as heavy metal pipes, concrete posts, brick, stone or other rigid foundation structure or encasement should be avoided.
- The post-to-box attachment details should be of sufficient strength to prevent the box from separating from the post top if the installation is struck by a vehicle. The exact support hardware dimension and design may vary, such as having a two-piece platform bracket or alternative slot-and-hole locations. The product must result in a satisfactory attachment of the mailbox to the post, and all components must fit together properly.

- The minimum spacing between the centers of support posts should be the height of the posts above the ground line. Mailbox support designs not described in this regulation are acceptable if approved by the jurisdiction.

The Department's [*Standard Plans, Index 110-200*](#) and the [*AASHTO Roadside Design Guide*](#) provide details on hardware, supports and attachment details acceptable for mailboxes located within the clear zone which conform to the above requirements.

D.8.d Bus Benches and Shelters

See **Chapter 3 – Geometric Design** for location criteria for bus benches and shelters. Additional criteria are provided in **Chapter 13 – Public Transit**.

In accordance with **Section 337.403, Florida Statutes**, existing utility poles must be relocated when *unreasonably* interfering with the "convenient, safe, or continuous use, or the maintenance, improvement, extension, or expansion" of public roads. Utility poles adjacent to road improvement projects, but not directly interfering with construction, should be considered for relocation, to the extent they can be relocated, to achieve the clear zone requirements of Table 3-12. Utility poles that cannot be relocated and will remain within the clear zone, should be approved through the exception process prescribed in **Chapter 14 - Design Exceptions**.

E BARRIERS, END TREATMENTS AND CRASH

CUSHIONS E.1 Roadside Barriers

Roadside barriers are used to shield motorists from roadside hazards and in some cases are used to protect bystanders, pedestrians, cyclists and/or workers from vehicular traffic. In still other cases, roadside barriers are used to protect bridge piers from vehicle impacts. Median barriers are similar to roadside barriers but are designed for vehicles striking either side and are primarily used to separate opposing traffic on a divided highway. Median barriers also may be used on heavily traveled roadways to separate through traffic from local traffic or to separate high occupancy vehicle (HOV) and managed lanes from general-purpose lanes. Barriers are further classified as rigid, semi-rigid and flexible which are

discussed in more detail below.

Barrier transition sections are used between adjoining barriers that have significantly different deflection characteristics. For example, a transition section is needed where a semi-rigid guardrail attaches to the approach end of a rigid concrete bridge rail, or when a barrier must be stiffened to shield fixed objects.

Requirements for bridge railings are provided in ***Chapter 17 – Bridges and Other Structures***.

E.2 End Treatments

End treatments include end anchorages, end terminals, and crash cushions. End anchorages are used to anchor a flexible or semi-rigid barrier to the ground to develop its tensile strength during an impact. End anchorages are not designed to be crashworthy for end on impacts. They are typically used on the trailing end of a roadside barrier on one-way roadways, or on the approach or trailing end of a flexible or semi-rigid barrier that is located outside the clear zone or that is shielded by another barrier system. End anchorages are discussed in more detail below.

End terminals are basically crashworthy anchorages. End terminals are used to anchor a flexible or semi-rigid barrier to the ground at the end of a barrier exposed to approaching traffic. Most end terminals are designed for vehicular impacts from only one side of the barrier, however some are designed for median applications where there is potential for impact from either side. End terminals are discussed in more detail below.

E.3 Crash Cushions

Crash cushions, sometimes referred to as impact attenuators, are crashworthy end treatments typically attached at the approach end of median barriers, roadside barriers, bridge railings or other rigid fixed objects, such as bridge piers. Crash cushions may be used in a median, a ramp terminal gore, or other roadside application. Crash cushions are discussed in more detail below.

E.4 Performance Requirements

Roadside barriers, transitions, end terminals, and crash cushions must be crashworthy as determined by full scale crash testing in accordance with specific

crash test criteria discussed in Section C. Descriptions of commonly used devices in Florida are described below. Section C also provides references where more information can be found on crashworthy devices.

E.5 Warrants

The determination as to when shielding is warranted for given hazardous roadside feature must be made on a case-by-case basis, and generally requires engineering judgment. It should be noted that the installation of roadside barriers presents a hazard in and of itself, and as such, the designer must analyze whether the installation of a barrier presents a greater risk than the feature it is intended to shield. The analysis should be completed using the [Roadside Safety Analysis Program \(RSAP\)](#) or in accordance with the [AASHTO Highway Safety Manual \(HSM\)](#).

Please see Section A for the considerations to be included when determining when to shield a roadside hazard.

The following hazards located within the clear zone are normally considered more hazardous than a roadside barrier:

E.5.a Above Ground Hazards

Above ground hazards are defined in Section B, Table 4 – 2 Lateral Offset. They include but are not limited to:

1. Bridge piers, abutments and railing ends
2. Parallel retaining walls with protrusions or other potential snagging features
3. Non-breakaway sign and lighting supports
4. Utility Poles
5. Trees greater than 4" in diameter measured 6" above ground.

E.5.b Drop-Off Hazards

Drop-off hazards are defined in Section B, Table 4-2 Lateral Offset.

E.5.c Canals and Water Bodies

Criteria for addressing canal and water body hazards is provided in Section B.2.c.

E.6 Warrants for Median Barriers

Median barriers shall be used on high speed, limited access facilities where the median width is less than the minimum values given in Chapter 3, Geometric Design, Table 3 – 16 Minimum Median Widths. For locations where median widths are equal to or greater than the minimum, median barriers are not normally considered except in special circumstances, such as a location with significant history of cross median crashes. Any determination to use a median barrier on limited access facilities must consider the need for barrier openings for median crossovers that are appropriately spaced to avoid excessive travel distances by emergency vehicles, law enforcement vehicles, and maintenance vehicles. The FDOT Design Manual may be referenced for additional criteria and guidelines for locating and designing median crossovers on limited access facilities.

On high speed divided arterials and collectors, median barriers are not normally used due to a number of factors that are very difficult, if not impractical, to address. Such factors include right-of-way constraints, property access needs, presence of at-grade intersections and driveways, adjacent commercial development, intersection sight distance and barrier end termination. However, provided these factors can be properly addressed, median barriers for these type facilities may be considered where median widths are less than minimum or where justified on the basis of significant crossover crash history.

See Section E for median barrier types and proper end treatment requirements. The ***AASHTO Roadside Design Guide*** and Department's [*Design Manual, Chapter 215 Roadside Safety*](#) and [*Standards Plans*](#) provide additional information and guidelines on the use of median barriers

E.7 Work Zones and Temporary Barriers

Clear zone widths for work zones, as a minimum, shall be the lessor of clear zone requirements provided in Table 4 – 1 Minimum Width of Clear Zone, Table 4 – 5 Clear Zone Width Requirements for Work Zones, or existing clear zone width. Clear zone widths in work zones are measured from the edge of Traveled Way defined

by the Temporary Traffic Control (TTC) Plan.

Table 4 – 5 Clear Zone Width Requirements for Work Zones

Work Zone Posted Speed (mph)	Travel Lanes & Multilane Ramps (feet)	Auxiliary Lanes & Single Lane Ramps (feet)
Curbed		
45 mph or less	4' Behind Face of Curb	4' Behind Face of Curb
Flush Shoulder		
30 – 40	14	10
45 – 50	18	10
55	24	14
60 – 70	30	18

When clear zone widths cannot be met, the use of temporary barriers shall be considered. Temporary barriers in work zones can serve several functions:

- Shield edge drop-offs, excavation, roadside structures, falsework for bridges, material storage sites and/or other exposed objects.
- Provide protection for workers.
- Separate two-way traffic.
- Separate pedestrians from vehicular traffic.

The decision to use temporary barriers in a work zone should be based on engineering judgement and analysis. There are many factors, including traffic volume, traffic operating speed, offset, and duration, that affect barrier needs within work zones. The Department's [Standard Plans](#), Index 102600 Series, [MUTCD](#) and the [AASHTO Roadside Design Guide](#) provide

additional information and guidance on the use of temporary barriers in work zones.

E.8 Barrier Types

Roadside barriers are classified as flexible, semi-rigid and rigid depending on their deflection characteristics when impacted. Flexible systems have the greatest deflection characteristics. Given much of the impact energy is dissipated by the deflection of the barrier and lower impact forces are imposed on the vehicle, flexible systems are generally more forgiving than rigid and semi-rigid systems. Rigid barriers, on the other hand, are assumed to exhibit no deflection under impact conditions so crash severity will likely be the highest of the three classifications.

In the following sections are basic descriptions of the barrier types commonly used in Florida for each these classifications. These commonly used barriers are those that are addressed in the Department's [Standard Plans](#) and [Design Manual](#). Those documents should be referenced for additional details and discussion on the proper use of these systems.

The basis for the Department's systems and devices, as well as many other generic and proprietary guardrail systems meeting **NCHRP Report 350** and/or MASH criteria, can be found in the following documents:

- [AASHTO Roadside Design Guide](#)
- [Federal Highway Administration \(FHWA\) Countermeasures that Reduce Crash Severity](#)
- AASHTO-Associated General Contractors of America (AGC)-American Road and Transportation Builders Association (ARTBA) Joint Committee Task Force 13 report, A Guide to Standardized Highway Barrier Hardware available at <http://www.tf13.org/Guides/>.

E.8.a Guardrail

The most commonly used barrier on new construction projects in Florida is the w-beam guardrail system detailed in the Department's [Standard Plans, Index 536-001](#) referenced as "General TL-3 Guardrail". This w-beam guardrail system, sometimes referred to as a strong post guardrail system, is a semi-rigid system, uses posts at 6'-3" spacing, 8" offset blocks, and

mid-span splices with a rail height of 2'-1" to center of the panel. This system was developed based on the 31" Midwest Guardrail System (MGS) and meets MASH Test Level 3 criteria. Compatible proprietary components may be referenced by the 31" height. This system can be used as a roadside barrier or in a double face configuration as a median barrier. Deflection space requirements for this system are provided in the Department's ***Design Manual, Chapter 215 Roadside Safety.***

The current 31" height system replaces the 27" height system (1'-9" to center of panel) that had been used for many years and still present on roadways throughout Florida. Section C.3 addresses requirements for upgrading existing 27" height systems.

The Department's ***Standard Plans, Index 536-001*** also provides details for a similar w-beam guardrail system referenced as "Low Speed, TL-2 Guardrail", with posts at 12'-6" spacing which meets MASH Test Level 2 criteria. While this TL 2 system may be used on low speed roadways 45 mph or less, it preferably should be used only on roadways with design speeds 35 mph and less to account for the potential for changes in posted speed limits and/or vehicles exceeding the design speed.

To achieve a minimum level of crash performance, guardrail installations shall have a minimum length of 75 feet with design speeds greater than 45 mph.

E.8.b Concrete Barrier

The most commonly used concrete barriers in Florida are detailed in the Department's ***Standard Plans, Index 521-001***. Details are provided for median application, shoulder application and pier protection. Additional information on these barriers is provided in the Department's ***Design Manual, Chapter 215 Roadside Safety.***

The Department's 32" height F-Shape concrete barrier wall system that has been in use for many years meets ***NCHRP Report 350*** Test Level 4 criteria and MASH Test Level 3 criteria. The Department is replacing this 32" F-Shape system with a 38" height single slope concrete barrier system which meets MASH Test Level 4 criteria. In addition to improved crash test performance, the single slope face provides for simpler construction.